

1. For the given cell: $\text{Fe}/\text{Fe}^{2+} (0.05)//\text{Ag}^+ (0.1)/\text{Ag}$

i) Write the overall cell reaction and derive Nernst equation using thermodynamic principles.

ii) Calculate E°_{cell} and E_{cell} at 25°C . (Given $E^\circ_{\text{Fe}^{2+}/\text{Fe}} = -0.44\text{V}$; $E^\circ_{\text{Ag}^+/\text{Ag}} = 0.68\text{V}$)

Sol: It is a quantitative relationship between electrode potential and concentration of species with which the electrode is reversible.

Let us consider a reversible reaction.



The reaction quotient for this reversible reaction, $Q = [\text{M}]/[\text{M}^{n+}]$

A thermodynamic equation which relates reaction quotient and decrease in free energy is given by,

$$\Delta G = \Delta G^\circ + RT \ln Q$$

where Q is the reaction quotient.

$-\Delta G$ represents the maximum work that can be obtainable from the electrochemical reaction. $-\Delta G = W_{\text{max}}$

For an electrochemical cell, W_{max} depends on

Number of Coulombs, i.e., No. of moles of electrons exchanged in redox reaction (n), multiplied by no. of coulombs per mole of electrons. $F(96,500 \text{ e/mol. E}) = nF$

Energy available per coulomb i.e., emf because volt = energy/Coulomb

Therefore $\Delta G = -nFE$




$$-nFE = -nFE^\circ + RT \ln \left(\frac{[\text{M}]}{[\text{M}^{n+}]} \right) \quad \text{Where } [\text{M}] = 1, \text{ for pure substances divide throughout by } -nF$$

$$E = E^\circ + \frac{RT}{nF} \ln \left(\frac{[\text{M}]}{[\text{M}^{n+}]} \right)$$

E° = Standard electrode potential, n = number of electrons exchanged in a redox reaction, R = Gas constant. $8.314 \text{ JK}^{-1} \text{ mol}^{-1}$, T = temp in Kelvin, F = Faraday 96500 C mol^{-1} . The equation reduces to following form at 298K ,

$$E = E^\circ + \frac{0.0591}{n} \log [\text{M}^{n+}]$$

Nernst equation may also be used to calculate. emf of electrochemical cells.



$$E_{\text{cell}} = E^\circ_{\text{cell}} - \frac{0.0591}{n} \log \frac{[\text{Fe}^{2+}][\text{Ag}]^2}{[\text{Fe}][\text{Ag}^+]^2}$$

$$E^\circ_{\text{cell}} = E_{\text{C}} - E_{\text{A}} = 1.12\text{V}$$

$$E_{\text{cell}} = 1.0994\text{V}$$


2. Identify the type of galvanic cell given below and justify your answer. Pt/H₂ (8atm)/HCl(0.3M)/H₂(2atm)/Pt. Calculate potential of the cell at 25°C.

Soln: The given Galvanic cell is “Electrode concentration cell” Because the same electrodes with different activity are in contact with same electrolyte.

$$E_{\text{cell}} = \frac{0.0591}{n} \log \frac{p_1}{p_2}$$

$$E_{\text{cell}} = 0.01779\text{V}$$

3. A decinormal electrode as cathode is coupled with a saturated calomel electrode as anode to form a cell. Write the cell representation and calculate the concentration of Cl⁻ ion in the saturated calomel electrode, if the cell potential measured is 0.0988 V at 25°C).



$$E_{\text{cell}} = E_{\text{R}} - E_{\text{L}}$$

$$= E^0 - 0.0591 \log(0.1) - E^0 - 0.0591 \log(x)$$

$$\frac{0.0988}{0.0591} = \log \frac{x}{0.1}$$

$$1.6717 - 1 = \log(x)$$

$$x = \text{Antilog}(0.6717)$$

$$x = 4.69\text{M}$$

4. What are the advantages and disadvantages of glass electrode?

Advantages of glass electrode:

- It is very easy to construct and simple to operate.
- The potential developed remains constant for long time.

- c) This electrode can be used with very small amount of the test solution.
- d) This electrode can be used even in the presence of oxidized impurities, reducing impurities, poison molecules etc.,
- e) The wide pH range from 0 to 14 can be measured using glass electrode.

Disadvantages:

- Because of high resistance of glass, a simple potentiometer cannot be used. It requires sensitive potentiometer for emf measurements.
- Alkaline error: It is a phenomenon that occurs at very high pH levels usually pH 9 or over. This is observed when the Sodium ion level is relatively so high that some of the H^+ ions in the gel layer around the sensitive electrode membrane are replaced by Na^+ ions. The electrode may eventually respond to Sodium ions instead of H^+ ions, giving a falsely lower pH value than the real result.

5. Calculate the potential of concentration cell given by, Fe/FeSO₄ (0.09 M)//FeSO₄ (2.48 M)/Fe at 298 K.

Soln:

$$E_{cell} = \frac{0.0591}{2} \log \frac{2.48}{0.09} = 0.04255V$$

9. Calculate the EMF of the following cell at 25°C. Ag/Ag⁺ (0.01M) // Ag⁺ (0.02 M)/ Ag (Given : R = 8.314 J/K/mol, F = 96500 C/mol)

Soln:

$$E_{cell} = \frac{0.0591}{n} \log \left[\frac{M(Cathode)}{M(Anode)} \right]$$

$$E_{cell} = \frac{0.0591}{1} \log \left[\frac{(0.02)}{(0.01)} \right]$$

$$E_{cell} = 0.01778 V$$